

HOW TO LOCK AN ADAPTER TO THE PALADIN RAIL





Step 1Install the Rail



Step 2Take the adapter



Step 3Clip it on the rail



Step 4Make sure the adapter is in the right place



Step 5Take the Paladin provided flexible hex driver



Step 6Tighten the 2 allen screws



Step 7The plate is now locked in place.