



**PPE Dispenser with rail
mounting kit, ABS plastic, small**



**Universal small box dispenser
for shoe cover, cap,
and other items Horizontal top
feed or vertical side feed
application**

**Item Number: IC275-HV-PM
JSN Number: not established**

**Dimensions:
13.75"W x 5.75"H x 7"D
Weight: 2lbs**

*Customer to define mounting preference
(horizontal or vertical) at time of order.*

Item Description:

- Mounts to "EVOLUTION," Fairfield-style Medical Equipment Management Rail using a snap action adapter with positive snap attachment lock feature.
- Integrated Allen screws provide the ability to lock the adapter in place on rail.
- Standard adapters are plastic with embedded anti-microbial compound.
- Adapter Plates are aluminum with an anti-microbial powder coat painted finish (AMF).
- Some accessories which require heavy-duty capacity will be provided with extruded aluminum adapter(s) and/or wall stand offs for added strength.
- Some plates have multiple holes to attach future products from different vendors without the need to purchase new plates each time.
- Some plates allowing adaptability to user demand, new codes or new vendor products without going to the wall and adjusting the rail itself.
- Alternate mounting kits available for other manufacturer's devices. Please contact your Sales Representative.
- Accessories now available for Modular, Hill-Rom/Wittrock and AMICO Style Rails.