



Rail Mounting Kit, Universal
for owner provided
half size tri-fold paper
towel dispensers
(i.e. Kimberly Clark, Georgia
Pacific)

Dispenser not included.



Item Number: IC401-P
JSN Number: A5080-RM

Dimensions: 11"W x 6"D x 7.5"W
Weight: 1lb

Item Description:

**** Does not include dispenser A5080**

- Mounts to "EVOLUTION," Fairfield-style Medical Equipment Management Rail using a snap action adapter with positive snap attachment lock feature.
- Integrated Allen screws provide the ability to lock the adapter in place on rail.
- Standard adapters are plastic with embedded anti-microbial compound.
- Adapter Plates are aluminum with an anti-microbial powder coat painted finish (AMF).
- Some accessories which require heavy-duty capacity will be provided with extruded aluminum adapter(s) and/or wall stand offs for added strength.
- Some plates have multiple holes to attach future products from different vendors without the need to purchase new plates each time.
- Some plates allowing adaptability to user demand, new codes or new vendor products without going to the wall and adjusting the rail itself.
- Alternate mounting kits available for other manufacturer's devices. Please contact your Sales Representative.
- Accessories now available for Modular, Hill-Rom/Wittrock and AMICO Style Rails.