



**Mounting Plate with side rail kit**  
**for Herman Miller C-Frame**  
**(Cart for illustration purposes only.**  
**Not included.)**

Add equipment rail to Herman Miller C-Frame for easy mounting of accessories to side of C-Frame unit.

**2 rails included.**

C-Frame unit sold separately

**Item Number: CF101-K**  
**Requires user defined**  
**JSN number**



**Item Description:**

- Mounts to “EVOLUTION,” Fairfield-style Medical Equipment Management Rail using a snap action adapter with positive snap attachment lock feature.
- Integrated Allen screws provide the ability to lock the adapter in place on rail.
- Standard adapters are plastic with embedded anti-microbial compound.
- Adapter Plates are aluminum with an anti-microbial powder coat painted finish (AMF).
- Some accessories which require heavy-duty capacity will be provided with extruded aluminum adapter(s) and/or wall stand offs for added strength.
- Some plates have multiple holes to attach future products from different vendors without the need to purchase new plates each time.
- Some plates allowing adaptability to user demand, new codes or new vendor products without going to the wall and adjusting the rail itself.
- Alternate mounting kits available for other manufacturer’s devices. Please contact your Sales Representative.
- Accessories now available for Modular, Hill-Rom/Wittrock and AMICO Style Rails.